

# LINK® Ramps

## ORDERING GUIDE

✂	Part #	Model	Width	Length	CHEVROLET		Ford				NISSAN			RAM			Mercedes		
					CITY EXPRESS	EXPRESS	E-SERIES	TRANSIT CONNECT	TRANSIT LOW ROOF	TRANSIT MED ROOF	TRANSIT HIGH ROOF	NV200	NV STD.	NV HIGH ROOF	PRO-MASTER CITY	PRO-MASTER LOW ROOF	PRO-MASTER HIGH ROOF	SPRINTER STD.	SPRINTER HIGH ROOF
Side Door Location	7850-A004	LB10 Step Mount**	24	81		X	X		X	X	X		X	X				X	X
	7850-A006	LB10 Step Mount**	30	81		X	X		X	X	X		X	X				X	X
	7850-A010	LB10 Step Mount**	30	90					X	X	X		X	X				X	X
	7850-A008	LB10 Step Mount**	36	81														X	X
	7850-A011	LB10 Step Mount**	36	90														X	X
	7842-A208	LB20 Flat Mount**	30	72											X	X			
	7842-A207	LB20 Flat Mount**	30	81											X	X			
	7842-A206	LB20 Flat Mount	30	99											X	X			
Rear Door Location	7842-A208	LB20 Flat Mount**	30	72	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
	7842-A207	LB20 Flat Mount**	30	81	X	X	X		X	X	X	X	X	X		X	X	X	X
	7842-A206	LB20 Flat Mount	30	99						X	X		X		X	X	X	X	X
	7842-A205	LB20 Flat Mount	30	108						X	X		X			X		X	X
	7842-A204	LB20 Flat Mount	36	81	X	X	X		X	X	X	X	X	X		X	X	X	X
	7842-A202	LB20 Flat Mount	36	99						X	X		X		X	X	X	X	X
	7842-A201	LB20 Flat Mount	36	108						X	X		X			X		X	X
	7842-A203	LB20 Flat Mount	36	126							X		X			X		X	X
	7842-A209	LB20 Flat Mount	47	99						X	X		X		X	X	X	X	X
	78524-A01	LT30 Extended**	24	119		X	X		X	X	X		X	X		X	X	X	X
	78524-A02	LT30 Extended**	30	119		X	X		X	X	X		X	X		X	X	X	X
	78524-A03	LT30 Extended**	36	119		X	X		X	X	X		X	X		X	X	X	X
	Swivel Ramp	7859-2102	LSR90 Swivel	30	99						X	X		X		X	X	X	X
7859-2112		LSR90 Swivel	30	108						X	X		X			X		X	
7859-2122		LSR90 Swivel	30	117						X			X			X		X	
7859-2101		LSR90 Swivel	36	99						X	X		X		X	X	X	X	
7859-2111		LSR90 Swivel	36	108						X	X		X			X		X	
7859-2121		LSR90 Swivel	36	117						X			X			X		X	
7859-2103		LSR90 Swivel	47	99						X	X		X		X	X	X	X	

(\*\*) Ramp is not available with a Spring Assist. **NOTE:** Ramp width & length measurements are in inches.

**WARNING:** Link products must be professionally installed by a trained technician when being placed into an Electric Vehicle (EV). Electric Vehicles have higher voltage batteries and cables and drilling into Electric Vehicles may cause serious bodily harm and possibly death. Link is not responsible for optional configurations or equipment that restrict the installation of this product in any way. Consult OEM body builder guides for additional installation guidelines.